

SB Connectivity WINYARD DMS

This manual is for connecting WINYARD DMS by LCS Computer Service GmbH

Written By: Rene Weber



INTRODUCTION

This manual describes the connection setup between FAST LTA Silent Brick System Version 2.15.0.9 and LCS Computer Service GmbH WINYARD DMS in Version 1.19.0222.0

Step 1 — General information

Requirements Compliance Option is necessary to enable various WORM volume types.

- (i) Installation and Connectors Installation and electrical connection as well as network connection are to be done as described in the manual Installation
- (i) Network Adjustments The network settings are to be adjusted as described in the manual Installation
- (i) Archive Creation Prior to the setup an archive has to be created consisting of WORM and Stage Bricks

Step 2 — Volume settings

Nama: Active Description:	Name: Safe Vescription:	Name: Archive Description:
Volume type: Year: Days: Hours: Mindex: WORDW with retention and versioning (RWRD triggered) 0 1 0 0 0 Safe file: 1 0 0 0 0 0 Safe file: 1 1 0 0 0 File demain:	Velome type: WORM with retention and versioning (RWRO triggered) V Safe Titles Reconstances Velome type: Velome type: Safe Title extension: Safe Title extension: Safe Title format: And Velome type: Velome type: Velo	Velame type: Years: Days: Hears: Hindes: WORM with retention and versioning (KWRO triggersd) Image: Control of the state of the s
Canad	Annual Contraction of the second seco	Consel

(i) WINYARD DMS utilizes two different volumes and supports retention as well as safe files

- Safe: Single File Archive
- Archive: Package / Project Archive
- Create two Volumes "Archive" and "Safe"
 - Volume Type "WORM with Retention and Versioning (RWRO trigger)". Retention period may be set to 1 day.
 - Retention Period may be set to 1 day. Will be set per file by WINYARD DMS.
 - Safe Files enabled in XML
 - No 0-byte archival

Step 3 — Create user

System Administration (Welcome) If Sensoras) Mortivis) Mor	Add SMB User Image: State of the state o	Refresh	 WINYARD DMS uses a dedicated user for the communication to the Network share. The user may be A local user An active directory user Depending on the type create a new local user under settings >> users
			 or join the active directory

Step 4 — Share settings

Target Volume:	
Share Path: /	
Share Name: Safe	
Read Only	
Case Sensitive	
Group/User Permissions:	
Public	
Add Permission E Remove Permission	
winyardservice	Type User
winyardservice	USEI

- Create on share for each of the two volumes
- Naming should be "Safe" and "Archive" as for the volume
- Make sure to choose the correct user for WINYARD DMS

Step 5 — Set up WINYARD DMS

(i) Get in touch with LCS Computer Service GmbH in order to set up WINYARD DMS